

## *istruzioni montaggio battitacco*



### ATTENZIONE/WARNING



*Please read these instructions through before attempting to fit this sill door. Please take appropriate safety measures when fitting this part. Please seek the assistance of a competent mechanic if you are inexperienced in working on your vehicle. Park the Alfa Romeo safely on solid ground and engage the hand brake before working on your vehicle!*

**THIS SILL DOOR IS INTENDED FOR TRACK USE ONLY**

*Leggete con attenzione queste istruzione prima di procedere col montaggio del battitacco. Adottate adeguate misure di sicurezza quando montate il battitacco. Richiedete l'aiuto di un meccanico esperto se non siete pratici a lavorare sul vostro veicolo. Parcheggiare l'Alfa Romeo su una superficie solida e tirare il freno a mano prima di lavorare sul vostro veicolo!*

**QUESTO BATTITACCO PUO' ESSERE USATO SOLO IN PISTA**

1. Pulire accuratamente la superficie:



2. Facoltativo: incollare una striscia adesiva colorata (non compresa nel kit) in corrispondenza del logo Alfa Romeo per dare un tocco di colore alla vostra personalizzazione





3. Stendere la colla (Bostik SuperChiaro o Pattex, colla non compresa nel kit) lungo il bordo come mostrato in figura



4. Attendere qualche minuto poi applicare la soglia battitacco in modo che risulti centrata rispetto alla cornice esistente sulla plastica, pigiando con le dita in modo da far aderire adeguatamente . Nella figura seguente il risultato finale!!!





